EMX3 SOFT STARTER

Take control from the start

AuCom

RIGHT FROM THE START The EMX3 is a comprehensive motor management system for the most demanding soft starting and stopping applications.

With an impressive range of features, the EMX3 delivers superior performance and an unprecedented level of flexibility in a compact and user-friendly package.

The EMX3 doesn't just start and stop your machinery with Constant Current and Current Ramp, it also features the innovative XLR-8 Adaptive Acceleration Control. XLR-8 gives you the ability to precisely manage your starting and stopping acceleration, reducing downtime and eliminating water hammer problems.

The EMX3 is easy to use during installation, commissioning, operation and even troubleshooting.

Quick setup gets your machinery running in next to no time, informative screens advise your operator on the performance of your motor and real language trip messages pinpoint exactly where any issues lie.

Options for control wiring from the top, bottom or left side provide greater flexibility, plus unique wiring looms and cable retainers make for a faster, tidier install.




Take control from the start

We've packed the EMX3 with features designed to make your life easier, including real-language feedback messages, so you don't have to look up codes to know what's happening.


We also use real-time graphs of motor operating performance and current, intended to quickly and clearly illustrate exactly how your motor is performing.

With real-time metering displays and a 99-place event log recording time-stamped details of operation and performance, it has never been easier to track how your motor is behaving.

The keypad is easily mounted on the exterior of your enclosure, using an optional keypad mounting kit. When mounting multiple soft starters in a single enclosure, this allows centralised control from a single location, with all the relevant information. Mount a number of displays next to each other for quick diagnosis of problems. (IP65 when mounted).







The EMX3 has been designed for ease of use, and the user-friendly menu is no exception. After a tidy installation, a quick setup guide helps you configure the starter for common applications by suggesting a typical setting, which you can then fine tune to suit your needs, all accessible from the easy to use keypad.

If space is at a premium in your motor control centre, the EMX3's compact size will save you space and trouble. Internal bypass contactors, built-in monitoring and indicators, and extensive on-board input and output functionality reduce the need for space and cost of external equipment, as well as simplifying installation.




METERING AND MONITORING

The EMX3 delivers an extensive range of information to replace an additional power meter (Amps, kW, kVA, pf).

PROGRAM MULTIPLE UNITS

When programming multiple units, simply plug the keypad into different starters for immediate download of your data. No fuss, no trouble – a smoother start in every sense.



Features and options

ADVANCED OPERATION

To meet the unique requirements of your application, the EMX3 offers a range of advanced features. The EMX3 meets the needs of specific applications including:

- Pumping (eg high head applications)
- Compressors (optimising load control)
- Bandsaws (easy blade alignment)
- Irrigators (built-in timer)

SIMULATIONS

Need to test the installation before connecting a motor? The EMX3 simulation functions let you test the soft starter's operation, external control circuits and associated equipment without connecting the soft starter to line voltage or a motor. The EMX3 has three simulation modes:

Run simulation: simulates a motor starting, running and stopping to ensure correct installation.

Protection simulation: simulates activation of each protection mechanism to confirm correct protection response.

Signalling simulation: simulates output signalling.

REMOVABLE CONNECTORS & UNIQUE WIRING LOOM

Installation is easy with plug-in control terminal blocks. Simply unplug each block, complete the wiring and re-insert the block.

Using the EMX3's unique and flexible cable ways, cables can be efficiently organised for wiring from either the top, left or from below.

| Feature Sets | EMX3 |
|--|------|
| MOTOR CONTROL | |
| Motor sets | 2 |
| Constant current and current ramp start | • |
| XLR-8 adaptive control starting/stopping | • |
| Kickstart | • |
| Coast to stop and TVR stop | • |
| DC brake | • |
| Jog (forward and reverse) | • |
| Inside delta (6 wire) control | • |
| MOTOR PROTECTION | |
| Motor thermal model | • |
| Motor thermistor | • |
| Current imbalance | • |
| Under/Overcurrent | • |
| Phase sequence | • |
| Phase loss | • |
| Powerloss | • |
| INTEGRATION AND MANAGEMENT | |
| Multi-language graphical display | • |
| I/O expansion options | • |
| Analog output | • |
| Emergency run | • |
| SCR fail PowerThrough operation | • |
| Auto restart | • |
| COMMUNICATIONS OPTIONS | |
| Modbus RTU | • |
| Profibus | • |
| DeviceNet | • |
| Modbus TCP | • |
| Profinet | • |
| Ethernet/IP | • |
| ACCESSORIES | |
| Remote keypad | • |
| Finger quards | • |
| | |

CURRENT RATINGS

| | Light | Medium | Heavy | Severe | |
|--------------------|---------------------|----------------------|---------------------|----------------------|--|
| Internal Bypass | AC53b 3.0-10:350 | AC53b 3.5-15:345 | AC53b 4.0-20:340 | AC53b 4.5-30:330 | |
| EMX3-0023B | 23 A | 20 A | 17 A | 15 A | |
| EMX3-0043B | 43 A | 37 A | 31 A | 26 A | |
| EMX3-0050B | 50 A | 44 A | 37 A | 30 A | |
| EMX3-0053B | 53 A | 53 A | 46 A | 37 A | |
| Internal Bypass | AC53b 3.0-10:590 | AC53b 3.5-15:585 | AC53b 4.0-20:580 | AC53b 4.5-30:570 | |
| EMX3-0076B | 76 A | 64 A | 55 A | 47 A | |
| EMX3-0097B | 97 A | 82 A | 69 A | 58 A | |
| EMX3-0100B | 100 A | 88 A | 74 A | 61 A | |
| EMX3-0105B | 105 A | 105 A | 95 A | 78 A | |
| EMX3-0145B | 145 A | 123 A | 106 A | 90 A | |
| EMX3-0170B | 170 A | 145 A | 121 A | 97 A | |
| EMX3-0200B | 200 A | 189 A | 160 A | 134 A | |
| EMX3-0220B | 220 A | 210 A | 178 A | 148 A | |
| EMX3-0255B | 255 A | 231 A | 201 A | 176 A | |
| EMX3-0350B | 350 A | 329 A | 284 A | 244 A | |
| EMX3-0425B | 425 A | 411 A | 355 A | 305 A | |
| EMX3-0500B | 500 A | 445 A | 383 A | 326 A | |
| EMX3-0580B | 580 A | 492 A | 425 A | 364 A | |
| EMX3-0700B | 700 A | 592 A | 512 A | 438 A | |
| EMX3-0820B | 820 A | 705 A | 606 A | 516 A | |
| EMX3-0920B | 920 A | 804 A | 684 A | 571 A | |
| EMX3-1000B | 1000 A | 936 A | 796 A | 664 A | |
| Non Bypassed | AC53a 3-10:50-6 | AC53a 3.5-15:50-6 | AC53a 4-20:50-6 | AC53a 4.5-30:50-6 | |
| EMX3-0255C | 255 A | 231 A | 201 A | 176 A | |
| EMX3-0360C | 360 A | 360 A | 310 A | 263 A | |
| EMX3-0380C | 380 A | 380 A | 359 A | 299 A | |
| EMX3-0430C | 430 A | 430 A | 368 A | 309 A | |
| EMX3-0620C | 620 A | 620 A | 540 A | 434 A | |
| EMX3-0650C | 650 A | 650 A | 561 A | 455 A | |
| EMX3-0790C | 790 A | 790 A | 714 A | 579 A | |
| EMX3-0930C | 930 A | 930 A | 829 A | 661 A | |
| EMX3-1200C | 1200 A | 1200 A | 1200 A | 1071 A | |
| EMX3-1410C | 1410 A | 1410 A | 1319 A | 1114 A | |
| EMX3-1600C | 1600 A | 1600 A | 1600 A | 1353 A | |



All ratings are at 40 $^{\rm o}\text{C}$ and <1000 metres. To calculate inside delta ratings, multiply by $1.5\,$ B = Internally bypassed, C = Non-bypassed Larger models available on request.

The future starts with AuCom

We develop motor control products for industrial applications across the world. Our focus on research and development, as well as manufacturing, supply and support, ensures that when you choose to work with AuCom, you're working with a global leader. Almost 40 years of experience added to our expertise and ability means you can rely on us to get it right from the start.

OUR APPROACH

We start with a challenge or application, working with you to define and develop a solution that's not only fit for purpose today, but fully supported into tomorrow.


OUR PEOPLE

The power behind our success doesn't rely on our innovative products alone. Our people play a pivotal role. That's why, with AuCom, it's always personal. Combining dedication and experience with ability and passion, we don't just listen more closely, we draw on the breadth of our expertise to better understand your unique requirements and offer real solutions and ongoing support.


OUR PARTNERS

We choose partners that are experts, not only in soft start and motor control, but in understanding the needs of their industry. We work closely with our partners to ensure customers receive only the best support and advice.






AuCom is accredited to ISO9001:2000, with all products designed and tested to international standards such as IEC 60947-4-2, UL 508, CCC and CISPR-11. All of our products are thoroughly tested in certified facilities and in the field before release, and every soft starter is tested before dispatch.




EMX3 dimensions


COMPACT DESIGN

The design of the EMX3 allows for multiple units to be mounted side by side, or in a bank of starters due to the flexibility in cabling options. Internally bypassed starters further reduce the overall size of your soft starter.






EMX3-0500B ~ 1000B



EMX3-0255C






EMX3-0360C ~ 1600C

| | Α | В | С | D | E | F | Weight kg (lbs) | | |
|------------|---------------|--------------------------|----------------|---------------|---------------|-----------------|--------------------|--|--|
| mm (inch) | | | | | | | | | |
| EMX3-0023B | | | | | | | | | |
| EMX3-0043B | | | | | 192 | N/A | 4.2 | | |
| EMX3-0050B | | | | | (7.6) | 11/6 | (9.3) | | |
| EMX3-0053B | 156 | 124 | 295 | 278 | | | | | |
| EMX3-0076B | [6.2] | [4.9] | [11.7] | (10.9) | | | 4.5 (9.9) | | |
| EMX3-0097B | | | | | 223 | | | | |
| EMX3-0100B | | | | | (8.8) | N/A | 5 (11.0) | | |
| EMX3-0105B | | | | | | | | | |
| EMX3-0145B | | | | | | | 14 [30.9] | | |
| EMX3-0170B | 282 | 250 | 438 (17.3) | 380 (15.0) | 250 (9.9) | N/A | 14.2 (31.3) | | |
| EMX3-0200B | (11.2) | [9.9] | | | | | 45 (00.4) | | |
| EMX3-0220B | | | | | | | 15 (33.1) | | |
| EMX3-0255B | | | | | | | 26 (57.3) | | |
| EMX3-0350B | 424 (16.7) | 376 (14.9) | 440 (17.4) | 392 (15.5) | 298 (11.8) | N/A | | | |
| EMX3-0425B | | | | | | | 29.4 (64.8) | | |
| EMX3-0500B | | 433 320 [17.1] [12.6] | | | 295 (11.7) | N/A | 50 | | |
| EMX3-0580B | | | 640 [25.2] | 600 [23.7] | | | (110.2) | | |
| EMX3-0700B | 433 | | | | | | 63.5 | | |
| EMX3-0820B | - | | | | | | (140.0) | | |
| EMX3-0920B | | | | | | | 64 | | |
| EMX3-1000B | | | | | | | (141.1) | | |
| EMX3-0255C | 390 (15.4) | 320 (12.6) | 460 (18.2) | 400 (15.8) | 279 (11.0) | N/A | 23 (50.7) | | |
| EMX3-0360C | | | | | | | | | |
| EMX3-0380C | | | | | | | 36 (79.4) | | |
| EMX3-0430C | | | | | | | | | |
| EMX3-0620C | 430 (17) | 320 (12.6) | 689 (27.2)* | 522 (20.6) | 300 (11.9) | 696 (27.5)** | | | |
| EMX3-0650C | | | | | | | 39.5 (87.1) | | |
| EMX3-0790C | | | | | | | | | |
| EMX3-0930C | | | | | | | 51.5 (113.5) | | |
| EMX3-1200C | | | | | | | 128.5 (283.3) | | |
| EMX3-1410C | 574 (22.6) | 500 (19.7) | 856 (33.8)* | 727 (28.7) | 361 (14.3) | 862 (34)** | 130 (286.6) | | |
| EMX3-1600C | | | | | | | 140 (308.6) | | |

^{*} Dimension C is the height when input and output busbars are at the same end of the unit (top in/ top out or bottom in/bottom out).

 $^{** \ \}mathsf{Dimension} \ \mathsf{F} \ \mathsf{applies} \ \mathsf{for} \ \mathsf{either} \ \mathsf{top} \ \mathsf{in/bottom} \ \mathsf{out} \ \mathsf{or} \ \mathsf{bottom} \ \mathsf{in/top} \ \mathsf{out} \ \mathsf{configuration}.$



New Zealand

123 Wrights Road, P0 Box 80208, Christchurch 8440, New Zealand T +64 3 338 8280 F +64 3 338 8104

China

203-1 JH Plaza, 2008 Huqingping Road, Shanghai 201702, China T +86 21 5877 5178 F +86 21 5877 6378

Germany

Borsigstraße 6, 48324 Sendenhorst, Germany T +49 2526 93880 0 F +49 2526 93880 100

Middle East

10th Floor, Swiss Tower, Jumeirah Lakes Towers, Dubai, UAE T+971 4279 8349 F+971 4279 8399

North America

2528 Lovi Road, Building 2-2A, Freedom, PA 15042, USA T 855 928 2666 (855 9 AUCOM NA), +1 724 987 4952 F +1 724 510 3005

Https://my.aucom.com

For more information and your local contact visit www.aucom.com



RIGHT FROM THE START